

WARNING ; PRE-LOADED ROLLING ROLLER

To assemble the recall roller insert it on the proper supports and in the correct position as down in the picture on its label

“THE BLACK BAND HIGHLIGHTED ON THE PAPER(on the right side of the roller head)SHOWS THE POSITION OF THE SAFETY PIN”

Position the roller with the safety pin (held down by the paper seal) under the roller; removing the paper seal will let the safety pin spring out the roller

Rotate it by hand in the winding direction and release it immediately
The loaded roller will wind up the belts raising the shutter

DO NOT RELEASE THE SAFETY PIN ON THE ROLLER UNTIL THE SHUTTER HAS BEEN PROPERLY ASSEMBLED AND MOUNTED

In case you should happen to unwind the roller before completing the assembling,REWIND IT following the winding direction of rotation and for the number of rounds shown on the roller itself.

Block it by reinserting the safety pin

To repeat the preceding operations

